

Wildlife Materials International, Inc.

TRX-10S Receiver

TO CHANGE BATTERY PACK:

After your warranty has expired, a battery pack can be changed at home. (When the receiver is under warranty, we change the battery at our facility, and then charge it, retune and recalibrate to insure quality performance.)

The battery is located in the **upper back, thicker half** of receiver.

INSTRUCTIONS: PLEASE READ BEFORE ACTING

1) Look at receiver's faceplate. On each side of receiver's upper section, remove 2 screws (a total of 4 screws must be removed).

MOVE SLOWLY and GRADUALLY

2) Lift the case's top section off. Place this top section on a flat surface so that you can see the battery pack in a metal holder. (DO NOT TOUCH circuitry in bottom half of receiver).

3) Unplug the white plastic Molex connector of old battery pack. Remove the two screws that will free the metal battery holder. Remove old battery pack.

4) Insert new battery. Plug in the Molex connector of new battery pack, fit into battery holder and tighten down the two battery holder screws.

5) Fit top section of case to the bottom section. Make sure the two sections are aligned, with corners smooth and screw holes matched. Tighten the two screws on each side of the case's top section. Make sure wires are not pinched.

6) **CHARGE BATTERY FOR 16 TO 24 HOURS.**

7) Test receiver. Hopefully it will not need to be retuned or recalibrated.

WARNING: Batteries installed incorrectly can cause wiring to burn up and/or batteries to explode. Be sure wires are not crimped when you put the unit back together.

Wildlife Materials International, Inc.

1202 Walnut Street Murphysboro, IL 62966 USA

Phone: 1-800-842-4537

FAX: 618-687-3539

FIVE-YEAR WARRANTY on ELECTRONICS